

Product Data Sheet

Descaler – Scale Build Up Remover

The first non-hazardous descaling solution for dish machines and coffee machines.

Product Description

Descaler is concentrated solution used for removing scale build up from automatic dishwashing machines, glasswashers and coffee machines.

Descaler is the first non-hazardous descaling solutions.

Characteristics

- Clear, slightly coloured, mobile liquid
- Odour: very slight odour
- pH <2
- Non-hazardous

Tools / Safety Equipment

- Rubber gloves
- Goggles
- Plastic apron
- Coveralls

Safety

Avoid contact with skin and eyes. Causes burns. Wear suitable protective clothing and face protection when handling this product.

Application Procedure

1. Read MSDS prior to use.
2. Read the safety instructions on label before use.
3. Drain the dishwasher and remove all food soils
4. Refill with fresh water
5. Add 500ml of Descaler to the water
6. Run machine for 10 minutes
7. In the case of automatic machines – run consecutive cycles until the machine has run for 10 minutes

First Aid

- If poisoning occurs, contact a doctor or Poisons Information Centre (Ph: 131 126)
- If swallowed, do NOT induce vomiting. Give a glass of water
- If skin contact occurs, remove contaminated clothing and wash skin thoroughly.
- If in eyes, hold eyes open, flood with water continuously for at least 15mins and see a doctor.

Pack Sizes

3 x 5Lts, 25Lt